

ALTERNATE SYMBOL AND ARROW DIRECTIONS: LEFT, RIGHT OR BOTH




SIGN	DIMENSIONS (INCHES)										
	A	B	C	D	E	F	G	H	J	K	L
MIN.	5	7-1/2	9 1/16	3/4	3/8	7/16	2-1/8	3/8	1/4	3/4	3/4

COLORS

LEGEND & ARROW - BLACK
BACKGROUND & SYMBOLS - WHITE

PEDESTRIAN PUSH BUTTON SIGN



TYPE B

PEDESTRIAN PUSH BUTTON

1. SHAPE BACK OF CASTING TO FIT CURVATURE OF POST.
2. PROVIDE COVER FITTING FOR TOP OF POST, WHEN PPB IS MOUNTED ON PEDESTRIAN PUSH BUTTON POST.
3. INSTALL PUSHBUTTON ON CROSSWALK SIDE OF STANDARD.

APPROVED BY


aus

DATE

3/3/92

PEDESTRIAN PUSHBUTTON SIGNS

DEPARTMENT OF PUBLIC WORKS



DRAWING
NO.

E-61